

# MOVE&LEAD



# EXECUTIVE SIT-STAND DESK MOVE&LEAD

## OPERATING INSTRUCTIONS

### SAFETY AND WARNINGS

**Inappropriate use of this product may cause property or bodily injury.**

**Check surroundings on all sides before using the desk. Do not place any objects taller than 630 mm under the desk.**

**Desks should not be used in environments with high humidity or dampness.**

**If you need to move the desk, DO NOT lift it only by holding the desktop. Lifting this way can stress the fasteners connecting the frame to the desktop.**

**Please provide this operation manual to any users, installers, or support personnel operating the product.**

### USAGE

The sit-stand has 2 electric lifting columns.

The desk height is adjustable so the desktop can be fixed for most suitable user's position. These desks are designed only for ergonomic sit-stand position.

Do not move around, crawl or lie under the desk.

Do not sit or stand on the desk desktop. Any other use is at user's risk.

### SETUP AND INSTALLATION

Choose a placement for the desk that is a safe distance from window frames, radiators, furniture etc.

Once the desk has been assembled, adjust the feet so that the desk is level and does not shift its position.

After this, connect the desk to the outlet and the desk is ready for use. **For the first start of desk please press and hold "down" button for control box activation.**

### TROUBLESHOOTING

If your desk does not function properly (does not go up or down; does not move at all) please do the RESET:

- Press and hold "Down" button for 5 seconds.

This will reset control box of columns.

- Now the desk is ready for use.

If this does not work please contact your seller.



### IMPORTANT

40  
KG

**Functional load of desk is 40 kg.  
Do not exceed this given load.**

1  
MIN

**! Please keep in mind that time for continuous desk movement upwards or downwards is 1 minute.**

9  
MIN

**After 1 minute of unstopped operation there has to be a resting period of 9 minutes.**

38  
MM/S

**Travel Speed Up to 38 mm/s.**

## HARDWARE CONNECTION

### LID

There is a lid under the desktop for power unit access. It opens downwards and closes upwards with magnets.



### GROMMET

After hardware (monitor, laptop, charger, etc.) is connected to power sockets, cables could be routed through the grommet cover to the desktop surface.



### QI WIRELESS CHARGING

Qi wireless charger is integrated into the desktop (depending on the chosen desk type). Charger itself is hidden under the desktop and the place for charging your device is marked on the desktop. Place the compatible device on the marked place, beep will be heard and device will start.

